


# **RECMAR** *Products*

Phone (800) 793-9611 FAX (713) 944-4809 [www.recmar.com](http://www.recmar.com)

## **Wal Mount Installation Instructions –5100 Track**

1. Purchase appropriate mounting screws and anchors as needed (not provided). Hardware required varies depending on ceiling construction. Be sure the screw head fits through the slot in the track.
2. Cut track to length. Any miter saw or hack saw will easily cut the track. When splicing tracks together, be sure each cut is a clean perpendicular cut and remove any burrs.
3. Identify optimal location to screw track into ceiling. It is preferred to drive mounting screws into wall studs or solid supports. Anchors may be required if mounting directly to drywall ceiling.
4. Mark screw locations on the track to identify where to drill mounting holes.
5. Using a small drill bit, drill holes through the back of the track. Be sure to center these holes through the slot in the track. Adjust the location of the hole if it is not centered. Be careful not to damage the slot with a drill bit or screw.
6. Re-drill each hole with a larger bit sized to accommodate your mounting screws.
7. Position the track onto the wall and mark the location of the holes in the track on the wall.
8. Drill pilot holes into the ceiling at the locations marked in step #7. Insert anchors into holes if necessary.
9. Mount the track to the wall by driving screws through the track so that the slot in the track is facing towards you. The head of the screws should be hidden inside the track. Take care not to leave screw heads in a position where they may interfere with the path of the carriers. If your application requires wall to wall installation, insert the carriers prior to mounting the track to the ceiling.



10. If splicing track sections together for wider spans, align the tracks so that they form a straight line and are abutting one another. Minimize any gap between the tracks. No splicing hardware is required, but alignment is critical.
11. Slip the carrier heads into the end of the track with the body of the snap stud protruding through the slot in the track.
12. Screw the 5138 end caps into the ends of track by using a self tapping metal screw and inserting it through the hole in the end cap and screwing it into the back of the track. The stud of the end cap should be facing you when mounted.